

3. Troubleshooting

3.1 Preparation before troubleshooting

If the signs of a trouble appear, it is important to lecture on the countermeasure and treatment before becoming a big accident not to shorten the engine life.


When the signs of a trouble appear in the engine or a trouble occurs, grasp the trouble conditions fully by the next point and find out the cause of sincerity according to the troubleshooting. Then repair the trouble, and prevent the recurrence of the trouble.

- 1) What's the occurrence phenomenon or the trouble situation?
(e.g. Poor exhaust color)
- 2) Investigation of the past records of the engine
Check a client control ledger, and examine the history of the engine.
 - Investigate the engine model name and the engine number. (Mentioned in the engine label.)
Examine the machine unit name and its number in the same way.
 - When was the engine maintained last time?
 - How much period and/or time has it been used after it was maintained last time?
 - What kind of problem was there on the engine last time, and what kind of maintenance was done?
- 3) Hear the occurrence phenomenon from the operator of the engine in detail.
5W1H of the occurrence phenomenon : the investigation of when (when), where (where),
who (who), what (what), why (why) and how (how)
 - When did the trouble happen at what kind of time?
 - Was there anything changed before the trouble?
 - Did the trouble occur suddenly, or was there what or a sign?
 - Was there any related phenomenon.
(e.g. Poor exhaust color and starting failure at the same time)
- 4) After presuming a probable cause based on the above investigation, investigate a cause systematically by the next troubleshooting guide, and find out the cause of sincerity.

3.2 Quick reference chart for troubleshooting

It is important to thoroughly understand each system and the function of all of the parts of these systems. A careful study of the engine mechanism will make this possible. When problems arise, it is important to carefully observe and analyze the indications of trouble in order to save time in determining their cause. Begin by checking the most easily identifiable causes of difficulty. Where the cause of the difficulty is not readily apparent, make a thorough examination of the system from the very beginning, proceeding until the point of trouble can be determined. While experience is an important factor in pinpointing engine problems, careful study and understanding of the engine mechanism combined with good common sense will help you to rapidly become more expert at troubleshooting.

Chart 1



| | | Chart 2 | |
|-----------------------------|---|--|--|
| TROUBLE AND TROUBLESHOOTING | | CYLINDER OUTPUT IS UNEVEN COUNTERMEASURE | |
| Countermeasure | (I-1) Bleed air. (I-2) Disassemble and clean. (I-3) Replace. (I-4) Repair or replace. (I-5) Replace. (I-6) Tighten firmly. | (I -7) Disassemble and clean and repair replace. | |
| Cause and Effect | | | |
| Countermeasure | (II-1) Check and repair. (II-2) Replace. (II-3) Adjust. (II-4) Adjust. (II-5) Clean. | | |


| | | Chart 3 | |
|-----------------------------|--|--|--|
| Trouble and Troubleshooting | | POOR EXHAUST COLOR | |
| Countermeasure | (I-1) Check, repair or replace. (I-2) Replace. (I-3) Check, repair or replace. (I-4) Adjust. (I-5) Adjust. | (II-1) Clean. (II-2) Check, repair or replace. (II-3) Adjust. (II-4) Check, repair or replace. (II-5) Clean. | |
| Cause and Effect | | | |
| Countermeasure | (III-1) Clean. | (IV-1) Reduce load. (IV-2) Adjust quantity of oil. (IV-3) Clean. (IV-4) Clean. (IV-5) Reduce. with new oil. (IV-6) Clean. | |

Chart 4

TROUBLE AND TROUBLESHOOTING

TROUBLE WITH MARINE GEAR

| | | | | |
|-----------------------|--|--|---|--|
| Countermeasure | (I-1) Disassemble and clean. (I-2) Repair or replace. (I-3) Repair or replace. (I-4) Replace. (I-5) Repair. (I-6) Adjust. | (I-7) Replace. (I-8) Replace. (I-9) Adjust to correct position. (I-10) Reassemble. (I-11) Check for oil leakage and replenish. | (II-1) Review (I-1, I-11). (II-2) Reduce load. (II-3) Replace. (II-4) Check oil level and adjust. (II-5) Check water level and adjust. (II-6) Change oil. (II-7) Review manual. | (III -1) Replace. (III -2) Replace. (III -3) Eliminate dangerous rotation. |
|-----------------------|--|--|---|--|



| | | | |
|-----------------------|--|--|---|
| Countermeasure | (IV-1) Replace. (IV-2) Clean. (IV-3) Replenish oil and check. Replace bellofrom. (IV-4) Repair link system. | (V-1) Replace. (V-2) Replace. (V-3) Adjust lube oil adjustment valve. (V-4) Change oil. | (VI-1) Check and repair. (VI-2) Disassemble and clean. (VI-3) Replace. (VI-4) Repair or replace. |
|-----------------------|--|--|---|

TROUBLE AND TROUBLESHOOTING

ROTATION IS NOT SMOOTH


Countermeasure

(I-1) Lap.
(I-2) Replace.

(II-1) Clean.
(II-2) Replace.
(II-3) Replace.
(II-4) Correctly install pump.
(II-5) Clean.
(II-6) Replace.

(II-7) Bleed air and prime.
(II-8) Adjust.
(II-9) Adjust.

Cause and Effect



Countermeasure

(III-1) Replace.
(III-2) Adjust.
(III-3) Clean.
(III-4) Disassemble, wash and repair.

(IV-1) Reduce load.
(IV-2) Disassemble, check and repair.
(IV-3) Check and adjust.

| TROUBLE AND TROUBLESHOOTING | | Chart 6 KNOCKING | |
|-----------------------------|---|---|--|
| Countermeasure | (I-1) Increase injection pressure. (I-2) Replace. (I-3) Disassemble and lap. (I-4) Disassemble and repair. | (II-1) Delay injection timing. (II-2) Adjust standard injection pressure. | |
| Cause and Effect | | | |
| Countermeasure | (III-1) Adjust pump adjustment rack. | (IV-1) Check cooling water pump and lap valves. (IV-2) Replace. (IV-3) Replace. (IV-4) Replace with good fuel oil. (IV-5) Replace with good fuel oil. (IV-6) Check and repair. | |

TROUBLE AND TROUBLESHOOTING

TROUBLE WITH STARTING

| | | | | |
|------------------|---|---|---|--|
| Countermeasure | (I-1) Tighten. (I-2) Repair using sandpaper or replace. (I-3) Replace. (I-4) Repair using sandpaper and then grease. (I-5) Adjust. (I-6) Adjust. (I-7) Replace. | (II-1) Tighten. (II-2) Repair using sandpaper. (II-3) Replace. (II-4) Repair using sandpaper (Type 500 ~ 600). (II-5) Replace. (II-6) Undercut and repair or replace. (II-7) Replace. (II-8) Replace with thicker or shorter wire. (II-9) Charge. | (III-1) Prime well. (III-2) Adjust. (III-3) Clean out matter causing clogging. (III-4) Add fuel to fuel tank. (III-5) Open cock. (III-6) Clean. (III-7) Disassemble and repair or replace. (III-8) Drain water from fuel system and prime. | (IV-1) Lap. (IV-2) Lap. (IV-3) Replace. (IV-4) Clean or replace. (IV-5) Adjust. |
| Cause and Effect | | | | |
| Countermeasure | (V-1) Replace plunger and barrel as a unit. (V-2) Replace. (V-3) Disassemble and repair or replace. (V-4) Lap valves. (V-5) Bleed air. (V-6) Replace. | (VI-1) Adjust. (VI-2) Tighten firmly. (VI-3) Replace. (VI-4) Bleed air. | (VII-1) Lap valves. (VII-2) Adjust. (VII-3) (VII-4) (VII-5) Replace. (VII-6) Disassemble and repair or replace. (VII-7) Tighten tightening nuts uniformly. (VII-8) Replace. | (VII-1) Replace. (VII-2) Adjust. (VII-3) Move governor handle to acceleration position. (VII-4) Check and repair. (VII-5) Clean. |

| TROUBLE AND TROUBLESHOOTING | | INSUFFICIENT POWER OUTPUT | |
|-----------------------------|--|---|---|
| Countermeasure | (I-1) Replace. (I-2) Disassemble and repair or replace. (I-3) Lap valves. (I-4) Tighten firmly. (I-5) (I-6) Adjust. (I-7) (I-8) Clean. (I-9) Replace. (I-10) Repair. | (II-1) Clean nozzle hole or replace. (II-2) Lap or replace. (II-3) Lap or replace. (II-4) Tighten firmly. (II-5) Replace. (II-6) lean. | (III-1) Replace. (III-2) Repair. |
| Cause and Effect | <p>(I) Amount of oil supply from fuel injection pump inadequate</p> <ul style="list-style-type: none"> (1) Worn plunger (2) Sticking of plunger (3) Oil leakage from exhaust valve (4) Oil leakage from joint of high pressure pipe (5) Faulty adjustment of fuel pump <p>(II) Amount of fuel injection inadequate</p> <ul style="list-style-type: none"> (6) Inaccurate positioning of adjustment rack (7) Clogging of fuel filter (8) Clogging of fuel oil pipe (9) Damaged valve spring (10) Faulty supply pump <p>(III) Faulty governor</p> <ul style="list-style-type: none"> (1) Clogging of nozzle hole (2) Faulty valve seat (3) Sticking of valve needle (4) Loose high pressure pipe (5) Worn valve needle (6) Clogging of filter (1) Damaged governor bearing (2) Inaccurate length of governor link <p>(IV) Leakage of pressurized gas from inside cylinder</p> <ul style="list-style-type: none"> (1) Leakage of gas from suction/exhaust valves (2) Inadequate taper clearance (3) Worn upper part of cylinder liner (4) Worn piston ring (5) Sticking of piston ring <p>(V) Irregular fuel injection timing</p> <ul style="list-style-type: none"> (1) Early injection (2) Late injection <p>(VI) Clogged intake air filter</p> <ul style="list-style-type: none"> (1) Clogging of air filter <p>(VII) Miscellaneous</p> <ul style="list-style-type: none"> (1) Poor quality fuel oil (2) Clogging of exhaust line (3) Seizure of moving parts (4) Insufficient cooling water (5) Insufficient lube oil supplied | | |
| Countermeasure | (IV-1) Lap valves. (IV-2) Adjust. (IV-3) Replace. (IV-4) Replace. (IV-5) Disassemble and repair or replace. | (V-1) Adjust timing to delay injection. (V-2) Adjust timing to speed injection. | (VI-1) Clean. (VII-1) Replace with good fuel oil. (VII-2) Clean. (VII-3) Disassemble, check and repair. (VII-4) Lap cooling water pump suction/exhaust valves. (VII-5) Disassemble and clean lube oil pump and filter. |

Chart 8

TROUBLE AND TROUBLESHOOTING

MISCELLANEOUS TROUBLE

| | | | |
|------------------|---|---|--|
| Countermeasure | <p>(I-1) Tighten nuts. (I-2) Tighten nuts and insert pins. (I-3) Remove adjustment liner and adjust aperture, or replace. (I-4) Check teeth, shaft, and pushrod of gear for wear. Replace where necessary.</p> | <p>(II-1) Tighten adjustment valve. (II-2) Check and repair. (II-3) Clean. (II-4) Repair.</p> | <p>(III-1) Clean. (III-2) Add cooling water. (III-3) Disassemble and repair or replace. (III-4) Tighten adjustment valve. (III-5) Tighten safety valve. (III-6) Change lube oil. (III-7) Add lube oil. (III-8) Replace.</p> |
| Cause and Effect | | | |
| Countermeasure | <p>(IV-1) Adjust the amount of returning water or check the cooling water pump and lap valves. (IV-2) Reduce load. (IV-3) Clean and adjust.</p> | <p>(V-1) Open closed parts. (V-2) Check pump and repair. (V-3) Adjust amount of returning water. (V-4) Clean. (V-5) Check suction opening. (V-6) Reduction load.</p> | <p>(VI-1) Clean. (VI-2) Check pump and repair. (VI-3) Lessen lift or replace pump. (VI-4) Check suction opening. (VI-5) Eliminate causes for high cooling water temperature and constrict. (VI-6) Check and repair.</p> |

3.3 Troubleshooting (Concerning engine and fuel injection equipment)

| Malfunctions | Causes | Remedies |
|--|--|---|
| The engine does not operate 1. Fuel oil is not injected from the injection pump | 1. There is no fuel oil in the fuel tank 2. The fuel line from the fuel tank is blocked 3. The fuel is clogged 4. There is air in the fuel filter or the pump chamber 5. The accelerator linkage is not properly connected 6. The magnet valve wiring is broken or its armature is sticking 7. The feed pump blades are sticking, and therefore not operating 8. The drive gear or woodruff key is broken | Supply fuel and bleed the system Clean or replace Clean or replace Bleed the system Repair Repair or replace Repair or replace Replace |
| | 1. The drive gear or belt connections are incorrect 2. The injection pump is incorrectly installed on the engine 3. The roller holder assembly's roller or pin is worn excessively 4. The plunger is worn excessively | Repair Repair and adjust injection timing Replace the assembly Replace the distributor assembly |
| | 1. The nozzle or nozzle holder is functioning incorrectly | Inspect, then repair or replace |
| | 1. The pipe(s) to the injection pump is blocked or the fuel filter is clogged 2. The fuel oil contains air or water 3. The feed pump's delivery quantity (or pressure) is insufficient | Clean or replace the pipe(s) or fuel filter Bleed of air or replace the fuel oil Repair or replace |
| | 1. The injection timing is too advanced 2. The nozzle or nozzle holder is functioning incorrectly | Readjust the timing Inspect, then repair or replace |

| Malfunctions | Causes | Remedies |
|---|--|--|
| The engine exhaust contains smoke and the engine “knocks” | <ol style="list-style-type: none"> 1. The injection timing is incorrect 2. The nozzle or nozzle holder is functioning incorrectly 3. The injection quantity is excessive | <p>Readjust the timing Inspect, then repair or replace</p> <p>Readjust</p> |
| The engine output is unstable | <ol style="list-style-type: none"> 1. The fuel filter element is clogged and fuel oil delivery is poor 2. The amount of fuel or pressure delivered by the feed pump is too little 3. The injection pump is sucking air 4. The regulating valve is stuck in the open position 5. The plunger is sticking and does not travel its full stroke 6. The plunger spring is broken 7. The control sleeve is not sliding smoothly 8. The governor lever is not operating properly or is worn excessively 9. The delivery valve spring is broken 10. The delivery valve is not sliding properly 11. The nozzle or the nozzle holder is not functioning properly 12. The injection timing is incorrect | <p>Clean or replace</p> <p>Inspect and repair</p> <p>Inspect and repair</p> <p>Replace</p> <p>Replace the distributor assembly</p> <p>Replace</p> <p>Repair or replace</p> <p>Repair or replace</p> <p>Replace</p> <p>Repair or replace</p> <p>Inspect, and then repair or replace</p> <p>Readjust</p> |
| <p>Insufficient output</p> <ol style="list-style-type: none"> 1. The injection quantity is insufficient 2. The injection timing is too advanced and the engine is “knocking” 3. The injection timing is too retarded and the engine is overheating or the exhaust contains smoke | <ol style="list-style-type: none"> 1. The specified full-load injection quantity is not delivered 2. The control lever is not reaching the maximum speed position 3. The governor spring is weak and therefore the governed speed is too low 4. The plunger is worn 5. The delivery valve seating portions are damaged | <p>Readjust</p> <p>Readjust</p> <p>Replace</p> <p>Replace the distributor assembly Replace</p> <p>Readjust</p> <p>Readjust</p> |

3. Troubleshooting

| Malfunctions | Causes | Remedies |
|--|--|--|
| 4. The nozzle or the nozzle holder is not functioning properly | | Inspect and then repair or replace |
| The engine cannot reach its maximum speed | <ol style="list-style-type: none"> 1. The governor spring is too weak or is improperly adjusted 2. The control lever is not reaching the maximum-speed position 3. The nozzle's injection operation is poor | <p>Readjust or replace</p> <p>Readjust</p> <p>Repair or replace</p> |
| The engine's maximum speed is too high | <ol style="list-style-type: none"> 1. The governor spring is too strong or is improperly adjust 2. The governor flyweights or governor sleeve movement is not smooth | <p>Readjust or replace</p> <p>Repair or replace</p> |
| Idling is unstable | <ol style="list-style-type: none"> 1. The injection quantities are not uniform (the delivery valve is not operating properly) 2. The governor's idling adjustment is improperly adjusted 3. The plunger is worn 4. The plunger spring is broken 5. The rubber damper is worn. 6. The governor lever shaft pin is worn excessively 7. The feed pump blades are not operating properly 8. The regulating valve is stuck in the open position 9. The fuel filter element is clogged and therefore fuel oil delivery is poor 10. The nozzle or the nozzle holder is not functioning properly | <p>Inspect or replace</p> <p>Readjust</p> <p>Replace the distributor assembly</p> <p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Repair or replace</p> <p>Replace</p> <p>Clean or replace</p> <p>Inspect and then repair or replace</p> |

3.4 Troubleshooting by measuring compression pressure

Compression pressure drop is one of major causes of increasing blowby gas (lubricating oil contamination or increased lubricating oil consumption as a resultant phenomenon) or starting failure. The compression pressure is affected by the following factors:


- 1) Degree of clearance between piston and cylinder
- 2) Degree of clearance at intake/exhaust valve seat
- 3) Gas leak from nozzle gasket or cylinder head gasket

In other words, the pressure drops due to increased parts wear and reduced durability resulting from long use of the engine.

A pressure drop may also be caused by scratched cylinder or piston by dust entrance from the dirty air cleaner element or worn or broken piston ring. Measure the compression pressure to diagnose presence of any abnormality in the engine.

(1) Compression pressure measurement method

- 1) After warming up the engine, remove the fuel injection pipe and valves from the cylinder to be measured.
- 2) Crank the engine before installing the compression gage adapter.
 - a) Perform cranking with the stop handle at the stop position (no injection state).
 - b) See 4.2.3(2) in Chapter 4 for the compression gage and compression gage adapter.
- 3) Install the compression gage and compression gage adapter at the cylinder to be measured.
 - a) Never forget to install a gasket at the tip end of the adapter.
- 4) With the engine set to the same state as in 2)a), crank the engine by the starter motor until the compression gage reading is stabilized.




(2) Standard compression pressure

Engine compression pressure list (reference value)

| Model | Compression pressure at 250 min ⁻¹ MPa (kgf/cm ²) | | Deviation among cylinders MPa (kgf/cm ²) |
|-------------|---|---------------------|---|
| | Standard | Limit | |
| 3YM30 | 3.43 ± 0.1 (35 ± 1) | 2.75 ± 0.1 (28 ± 1) | 0.2 ± 0.3 (2 ± 3) |
| 3YM20/2YM15 | 3.23 ± 0.1 (33 ± 1) | 2.55 ± 0.1 (26 ± 1) | 0.2 ± 0.3 (2 ± 3) |

3. Troubleshooting

(3) Engine speed and compression pressure (for reference)



(4) Measured value and troubleshooting

When the measured compression pressure is below the limit value, inspect each part by referring to the table below.

| No. | Item | Cause | Corrective action |
|-----|---|--|---|
| 1 | <ul style="list-style-type: none"> Air cleaner element | <ul style="list-style-type: none"> Clogged element Broken element Defect at element seal portion | <ul style="list-style-type: none"> Clean the element. Replace the element. |
| 2 | <ul style="list-style-type: none"> Valve clearance | <ul style="list-style-type: none"> Excessive or no clearance | <ul style="list-style-type: none"> Adjust the valve clearance. (See 2.2.2(5) in Chapter 2.) |
| 3 | <ul style="list-style-type: none"> Valve timing | <ul style="list-style-type: none"> Incorrect valve clearance | <ul style="list-style-type: none"> Adjust the valve clearance. (See in Chapter2.) |
| 4 | <ul style="list-style-type: none"> Cylinder head gasket | <ul style="list-style-type: none"> Gas leak from gasket | <ul style="list-style-type: none"> Replace the gasket. Retighten the cylinder head bolts to the specified torque. (See 5.2.5 in Chapter 5.) |
| 5 | <ul style="list-style-type: none"> Intake / exhaust valve Valve seat | <ul style="list-style-type: none"> Gas leak due to worn valve seat or foreign matter trapping Sticking valve | <ul style="list-style-type: none"> Lap the valve seat. (See 5.2.2 in Chapter 5.) Replace the intake/exhaust valve. |
| 6 | <ul style="list-style-type: none"> Piston Piston ring Cylinder | <ul style="list-style-type: none"> Gas leak due to scratching or wear | <ul style="list-style-type: none"> Perform honing and use an oversized part. |