

ST60 and ST60+ Wind Display Master Reset Instructions

To perform a master reset you must hold down the **disp** key and the **true/app** key for 12 seconds. You will then hear 3 beeps and <u>dlr</u> will be shown on the screen you now want to simultaneously press the **vmg** key and **tack** key and release. You should now see <u>UCO</u> on the screen. Now hit the **disp** key 5 times until <u>FO</u> is shown. Hit the **vmg** key once now <u>F1</u> should be shown. Last w hit **disp** key once. Your display is now reset.



